

User Manual of ID Card Camera JVE-3103

● Product Accessories

- ID card camera
- USB cable
- User manual CD
- A clip

● Picture & Buttons



- 1、ON/OFF/Record video /Save video 2、Reset 3、photo/ audio button
4、Indicator light 5、Camera 6、MIC 7、USB port

● Technical Data

- 1) Main functions: record video and audio at same time, take photo, record audio alone
- 2) Video format: AVI, 1280*960 resolution
- 3) Picture format: JPG, 1280*960 resolution
- 4) Audio format: WAV
- 5) Internal memory: 2GB/4GB
- 6) USB: 2.0(Hs)
- 7) Recharging time: 2-3 hour
- 8) Built Li-rechargeable battery: can work for 2hours continuously
- 9) Operation systems: Windows ME/ 2000/ XP/ VISTA no need driver (Windows98 needs driver)

● **Operation directions**

◆ **Switch on**

Press ON/OFF button, yellow light and blue light on at the same time, two seconds later yellow light on which indicates it enters standby mode.

◆ **Record video**

Under standby mode, press ON/OFF button, blue light on which indicates it starts to record video. Press ON/OFF again, the blue light turns to yellow light after 2 seconds which indicates the video file is saved automatically and the camera back to standby mode.

◆ **Take photo**

Under standby mode, press photo/ audio button, blue light on, after 2seconds yellow light on which indicates one photo is taken and back to standby mode.

◆ **Record audio alone**

Under standby mode, press photo/ audio button for 2 seconds, yellow light and blue light on at the same time which indicates it starts to record audio. Press the button again for 2 seconds, the light turns to yellow light which indicates the audio file is saved automatically and the camera back to standby mode.

◆ **Switch off**

Under any mode, press the ON/OFF button for 2 seconds, all the lights turn off which indicates the camera is shut down or insert a clip into “reset” hole to shut down the camera.

◆ **Reset**

Insert a clip into the “reset” hole to restart the camera

◆ **Charging**

If the yellow light keeps flashing, it indicates low power. Connect the camera to computer via USB cable to charge the camera, the yellow light will flash slowly which indicates the camera is being recharged. Once the camera is full charged, the yellow stops flashing and keep on. Please remove the camera from computer after it is full recharged.

◆ **Playback video**

Connect the camera to your computer via USB cable to play back video.

◆ **Setting time**

- 1) Connect the camera to computer via USB cable
- 2) Insert the manual CD and find a file named GetSysTime
- 3) Click GetSysTime.exe to update the date and time same, after this, the time of the camera will synchronize with the time of computer when you restart it again.