

User Manual of Watch Camera JVE-3105A

● Product Accessories

- Watch camera
- USB cable
- User manual CD

● Picture & Buttons



1. Power on/off 2. USB port 3. Reset 4. Camera
5. Time adjustment key 6. Led

● Technical Data

- 1) Main function: Record video and audio at the same time, watch, usb drive
- 2) Video format: AVI, 640*480 resolution
- 3) Picture format: JPG, 640*480 resolution
- 4) Internal memory: 2GB/4GB/8GB
- 5) USB interface: 2.0 (Hs)
- 6) Charging time: 3-4 hours
- 7) Battery use time: built-in Li battery, 2 hours
- 8) Operation systems: No need for driver installation if the operating system is Windows ME/ 2000/ XP/vista or above (windows98 is excepted).

● **Operation**

◆ **Switch on**

Press the power-on/off button for some seconds, red light will turn on and flash 6 times, after that, the red light will keep on, indicating that the watch enters into the standby mode.

◆ **Recording video and audio**

Press the Power on/ off Button one time, red light will turn off, green light will flash continually, and it starts to recording video.

Press the Power on/off button, the green light will turn off and red light turn on, the video is saved and the device turns to standby mode.

◆ **Taking photo**

Press the power on/off button for some seconds under standby mode, red light will turn off, and green light turns on, the device enter into taking photo mode.

Press the power on/off button one time, red light flash one time, indicating that a photo is taken and saved automatically.

Press the power on/off button for some seconds, green light turns off and red light will keep on, then the watch back into standby mode again.

◆ **Switch off**

Press the reset button, the red light will turn off.

◆ **Reset**

Please press the Reset Button to restart when the watch does not work normally.

◆ **Charging**

In the power-off mode, connect the camera to computer via USB cable and charge it. The red light keeps on while being charged. When the red light turns off, it shows the camera is fully charged.

If the device if of low electricity, both red light and blue light flash slowly,the device will save the file and turn off automatically.

◆ **Playback video**

Connect the device to computer via USB cable and play back video on computer. Please make sure there is the playback software in the computer before connecting.

● **Attention**

- 1) You can check whether the device is fully charged while you can't turn it on.
- 2) When taking video continually, the system will automatically generate a new video file after each operation.
- 3) In the adequate light environment, keep the DV vertical and stable, you can get best video and images within a certain distance.
- 4) Connect to computer:

The time for computer with different system or configuration to identify the hardware is slightly different. During this period, please wait for a moment. If computer can't identify, please make sure your operating system, drivers and USB interface cable in good work order. Then connect again.

5) The device has a function of memorize by using built-in high-capacity polymer lithium battery. Please charge the battery fully after you have used out the battery. By doing so, you can access the maximum capacity of the battery, reaching the standard working hours

6) The device is high-Tec electronic product; please do not use it under high impulsive force and shaking or in a strong magnetic field and weak electric field area.